



Allstate Rubber Covebase

A Product of Stoler Industries

Dalton, Ga. 30722

1 706 277 1000 Fax: 1 706 277 4400

www.allstaterubber.com

Covebase Installation:

- 1 Use only adhesive recommended for Allstate rubber base.
- 2 Do NOT apply over vinyl wall covering.
- 3 Installer must apply enough glue to cover 75% of the base. Too little glue will cause an installation failure, NOT a product failure.
- 4 Heavy sunlight from direct or glass-filtered sources can cause fading.
- 5 Do NOT install an obviously defective product. If in doubt stop job. Call your supplier at once. Failure to do so voids and + all warranties.
- 6 Floor cleaners may cause staining during the course of normal maintenance. Wipe base off w/a soft cloth or clean sponge with clean water.
- 7 Install only on structurally sound surfaces, i.e. plaster, drywall, plywood, paneling or masonry.
- 8 Surface must be dry, clean and free of dirt, grease, loose paint + plaster, and old glue. Surface must be thoroughly cured.
- 9 Do NOT install over a nonporous surface (vinyl wall covering, epoxy paint etc)
- 10 The gap between the floor & wall should be no greater than ¼"
- 11 Adhesive, base + wall must be @ 68 degrees F for at least 48 hours before installation.
- 12 Press or roll base firmly into place immediately after installation. Do not allow glue to "skim" over.
- 13 Roll the base towards the last installed piece. This helps avoid gaps between sections.
- 14 Butt ends firmly together, so the top of the base fits snugly against the wall surface.
- 15 Remove any excess glue immediately w/a soft cloth dampened with water.
- 16 Do not score more than 20% of the back when making outside corners. This will void and + all warranties.
- 17 Do not use a heat gun at any time during the course of installation.