



STOLER INDUSTRIES

ALLSTATE RUBBER WALLBASE, RUBBER TILE & STAIRTREADS

BOX 2587-2220 S HAMILTON EXTENSION DALTON, GA 30722

1 706 277 1000 FX 1 706 277 4400

INSTALLATION OF OUTSIDE CORNERS:

At an outside corner, butt the next section of base to the last installed. Make sure the base is in the proper position on the wall, as you would install it. Take a pencil; mark the back of the base using the wall as a guide. This gives you the correct contour of the wall. Then turn the base face down with the reverse side face up, using a Crain 532 gouge, start under the top lip of the base (note: always gouge on the side of the line in the direction the base will be going, do not gouge on the center of the line). Make sure to only score the surface. The depth of this area at its deepest point should not exceed 20% of the base thickness. Gouging too deep will result in an unusable corner! No warranties apply if gouged too deeply! Gouge from the top of the base to the bottom. When completed, use the gouge to make two stress relief gouges at the bottom. In the thick part of the base at the top of the toe about one inch from each side of the center gouge, make the gouges downward approximately ½" long. This allows the corner to be easily formed. Pull up on the toe, turn it inside out, position base after applying glue, set in place and allow the toe to drop down to form a perfect corner. Do not use a heat gun during the course of installation.