

Stairtread Maintenance

- After installation and before first use, clean any + all excess adhesive. Follow instruction of adhesive manufacturer.
- At regular intervals the tread should be dusted and damp mopped to prevent any build up of dirt + any foreign material. Do not flood stairs. A non-abrasive cleaner should be used.
- If so required apply a NON-slip acrylic floor finish to the surface of the treads. We recommend a matte finish to minimize the appearance of a wet and unsafe floor. Taski/Lever Industrial or Johnson Wax are known manufacturers of such a product. Make sure that treads are thoroughly rinsed w/clean water as any left over residue may leave a sticky film.