



**Allstate Rubber Corp.**

Ozone Park, NYC 11416

1 718 526 7890 Fax: 1 718 849 1662

**“ALLSTATE RESILIENT FLOORING SINCE 1958”**

**MVT TILE MAINTENANCE INSTRUCTIONS:**

- Initial maintenance for Allstate MVT (lot #'s 9500 and up). After installation cover with heavy paper to protect floor from other trades. Do not apply any finish to this floor until original factory finish has worn off. This time frame can vary from job to job. Due to the original PUR (PUR=polyurethane) factory finish the floor can be installed and walked upon after the adhesive has cured without any additional finish needed. The PUR finish is extremely hardwearing and easy to maintain. After finish has worn off follow instructions below.
- For lot #'s under #9500: After all trades have finished work, flooring contractor should sweep floor clean of all debris & dust. This should be done with a brush broom. After a **minimum** of 72 hours (preferably after 1 week) floor should be scrubbed w/ a heavy-duty mechanical scrubber. Use a neutral detergent and a non-abrasive brush/pad. Rinse thoroughly with clean water. **These lots are for older + discontinued colors that may happen to still be in stock.**
- For lot #'s under #9500, initial maintenance + lot #'s above #9500 **after** finish has worn off. Allow floor to **completely** dry. Apply two thin coats of a metalized acrylic floor finish (**Do NOT USE A PASTE WAX!**) for vinyl. The Taski brand of products has often been used w/ MVT. Taski Ombre is a matte finish; the Taski Ultra is a high gloss finish. Reapply as needed. Do not apply more than 3 coats of any finish. The floor will then look dirty. Allow floor to dry between coats. After applying finish floor can then be buffed according to mfg's instructions. The advantages of metalized acrylic over wax are: they do not yellow, allowing touch ups instead of overall stripping; they are longer wearing than wax.
- Regular maintenance includes: Sweeping daily and regular washing of the floor with a neutral soap detergent. Buffing w/a light pad.

**SPECIAL NOTES:**

Avoid the excessive use of water while cleaning. All water must be **clean** and changed frequently.

Entrance mats will prolong the life of your floor and reduce maintenance costs.

Plain or solid color Uni floors require more maintenance and are **not** recommended or warranted for use as an overall field.

Taski products are available from Lever Industrial @ 1800 827 5427.

Specifications are subject to change without notice.

Smaller, closed areas may require more maintenance than larger open areas.