



SALES@ALLSTATERUBBER.COM

RUBBER TILE MAINTENANCE INSTRUCTIONS:

- 1 For newly installed floors; sweep, vacuum or brush off all construction debris. Wait seven (7) days before washing floor (adhesive must be fully cured). Use Taski Profi™ neutral stripper as discussed below.
- 2 Floor should be swept @ regular intervals.
- 3 Wash as needed. Use a mild detergent and clean water.
Or use a neutral PH cleaner such as Taski Profi. Do not allow the solution to dry on the floor!
Smooth tile: Scrub the floor w/a single disc machine (150-300 rpm) and soft nylon brush or red pad. For Textured floors: use a single disc machine (150-300 rpm) and a soft nylon brush only. Do NOT use a black or brown pad. Do NOT use high speed buffing machines. Profi can also be used w/a mop & bucket or automatic scrubber.
- 4 Pick up soiled cleaning solution w/ a wet/dry vacuum. Rinse with clean water after washing. Allow floor to thoroughly dry (1-4 hours, depending on local conditions)
- 5 If a finish is desired use only acrylics, **not** wax products!
- 6 Apply 2-3 thin coats of a metallized acrylic floor finish, i.e. TASKI Vision Matte (matte finish) or TASKI Vision Star (glossy finish). Too many coats and the floor will look dirty. Allow each coat of finish to dry before applying another coat. Allow enough time for the floor finish to dry before allowing any foot traffic. For detailed instructions, follow directions from floor finish manufacturer.

Taski WiWax™ is another cleaning product it contains detergent & polymers to clean and maintain rubber tile. It cleans away soil and leaves behind a protective non-buffable water proof and non-slip film. May be mopped on and does not yellow.

Repeat above steps as necessary.

NOTES:

1. Do not seal or “undercoat” this floor!
2. The use of entrance mats will prolong the life of your floor and reduce maintenance costs. The use of mats is also advised for entrances to kitchens, parking lots and wait stations.
3. Do not flood the floor with water during maintenance.
4. Always clean floor before buffing. Never buff a dirty floor.
5. Do NOT use a high speed buffing machine
6. Never use a brown or black scrubbing pad.
7. Do not buff too long in one place as burn marks may occur.
8. Never use steel wool or abrasive brushes.
9. Always use a neutral PH cleaning solutions (between 2 and 12)
10. Taski products are available through Johnson Diversy #1 800 827 5487
11. Specifications are subject to change without notice.