

QUARTZ TILE/MQT: Adhesive

Mapei Eco 360, XL Brand Encore 8600, Spray-Lock 9500

- Tile must be installed directionally MVT has a unique visual directional shading effect due to the manufacturing process.
- It must be installed with the directional arrows on the back of the tile aligned in the same direction.
- Do not mix tiles from different boxes or pallets.
- Start by laying all tiles from one box. Then start a new box.
- Install tiles from the last produced tiles sequentially to the first produced tiles to insure proper shade distribution.