

## STAIRTREAD: Installation Guide

- Stairtreads are for indoor installations only. Outdoor installations are NOT an approved application.
- Allstate Stairtread adhesive + nose caulking epoxy must be used for warranty to apply. Failure to use correct Allstate adhesive products voids any and all warranties. Allstate Stairtread adhesive + nose caulking epoxy must be used for warranty to apply.
- Nose caulking gun: We do NOT sell this. It is available from the factory direct. CDX North America@ 8181 Coleman Rd Haslett, Mi. 48840 Phone# 1 800 822 8114 Model #VBM 200X MR2
- A tight fit between treads + steps is essential.
- Stairs must be free of all foreign matter. Stairs must be clean of paint, sealers, grease, rust, varnish or any other surface treatment. Do not install over old tile or Stairtreads. Sand any smooth areas w/a 60 grit sandpaper.
- Treads, glue and stairs must be at 70 degrees (F) before installation for a minimum of 24 hours.
- Repair worn, uneven or misaligned edge of steps. If an open space exists underneath the nosing of the tread, fill it in using the nose caulking epoxy. Failure to do so will lead to installation failure. This is not covered under warranty.
- Any irregularities on the steps (holes, dished out steps, depressions) must be repaired before installation. If needed use a self-leveling underlayment, NOT a patch.

## STAIRTREAD: Installation Guide (cont.)

- Cut and dry fit treads before installation. Do NOT install treads with obvious defects. This voids any + all warranties.
- Treads must be installed so that they fit snugly from left to right and front to back. Do not leave any spaces from left to right or front to back.
- A hand roller is essential for a proper installation.
- Spread adhesive on the stair with appropriate trowel. Allow the adhesive to tack for 25-30 minutes, higher temps & lower humidity will shorten the time, lower temps and higher humidity will lengthen the time. Lay the stairtread into the glue. Push down and back on the tread so that the tread is firmly in place. Roll the tread with a hand roller.
- Clean any + all glue or caulking compound immediately before it hardens
- Do not wash treads or apply any treatments for 7 days after installation.
- Do not allow foot traffic for a minimum of 24 hours after installation.
- Wheeled traffic is not approved for use w/Stairtreads! This will void and all warranties.