

RUBBER TILE FLOOR: Maintenance Guide

1. For newly installed floors; sweep, vacuum or brush off all construction debris. Wait seven (7) days before washing floor (adhesive must be fully cured). Use Taski Profi™ neutral striper as discussed below.
2. Floor should be swept at regular intervals.
3. Wash as needed. Use a mild detergent and clean water. Or use a neutral PH cleaner such as Taski Profi. **Do not allow the solution to dry on the floor!**
 - Smooth tile:** Scrub the floor w/a single disc machine (150-300 rpm) and soft nylon brush or red pad.
 - For Textured floors:** use a single disc machine (150-300 rpm) and a soft nylon brush only. **Do NOT** use a black or brown pad. **Do NOT** use high speed buffing machines. Profi can also be used w/a mop & bucket or automatic scrubber.
 - Do NOT** use cleaners with a PH of pH>9 or greater.
4. Pick up soiled cleaning solution w/ a wet/dry vacuum. Rinse with clean water after washing. Allow floor to thoroughly dry (1-4 hours, depending on local conditions).
5. If a finish is desired use only acrylics, not wax products! Solid color (uni) tile must have a floor finish applied.
6. Apply 2-3 thin coats of a metallized acrylic floor finish, i.e. Hilway Direct Floor Finish Matte. Too many coats and the floor will look dirty. Allow each coat of finish to dry before applying another coat. Allow enough time for the floor finish to dry before allowing any foot traffic. For detailed instructions, follow directions from floor finish manufacturer.
7. Repeat above steps if necessary.

Finish Recommendations:

Taski WiWax™ is another cleaning product it contains detergent & polymers to clean and maintain rubber tile. It cleans away soil and leaves behind a protective non-buffable water proof and non-slip film. May be mopped on and does not yellow.

Taski Carefree, acrylic high solid finish, medium gloss.

RUBBER TILE FLOOR: Maintenance Guide (cont.)

NOTES

1. Allstate recommends waiting at least 72 hours prior to performing the initial cleaning; this will give the adhesive sufficient time to properly cure and dry.
2. Do not seal or "undercoat" this floor
3. Solid color tile (Uni) must have a finish applied to it.
4. The use of entrance mats will prolong the life of your floor and reduce maintenance costs. The use of mats is also advised for entrances to kitchens, parking lots and wait stations.
5. Do not flood the floor with water during maintenance.
6. Always clean floor before buffing. Never buff a dirty floor.
7. Do NOT use a high speed buffing machine.
8. Never use a brown or black scrubbing pad. This voids all warranties.
9. If buffing, Turn pad often to prevent build up.
10. Do not buff too long in one place as burn marks may occur.
11. Never use steel wool or abrasive brushes, acetone, gasoline or turpentine to clean your rubber flooring.
12. Always use a neutral PH cleaning solutions (between 2 and 12)
13. Taski products are available through Johnson Diversy #1 800 827 5487
14. Your job site conditions may require different maintenance procedures. Please test first to confirm suitability of above procedures.
15. Specifications are subject to change without notice.

JC 7.2016

allstaterubber.com

ALLSTATE RUBBER by Stoler Industries
2220 S Hamilton Extension Dalton, Georgia 30720
sales@allstaterubber.com

