

Vent Cove Base: Installation, Maintenance & Warranty

INSTALLATION:

Complete all other trades in or around the surfaces to receive BRP BASE. Areas should be clean, fully enclosed, and watertight. Ensure clean substrate surfaces to adhere BRP BASE with adhesive compatible with vinyl. Miter or use pre-molded outside corners. Cutting can be completed by chop saw or hot knife.

ADHESIVES:

Henry 440 cove adhesive or Liquid Nails Heavy Duty, Gorilla Heavy Duty, or DAP HD Max, Loctite PL Premium & Powergrab. Any vinyl compatible construction adhesive. Heavy Duty or oil based formula's preferred. Ensure adhesive is matched to substrate being permeable or non permeable.

MAINTENANCE:

Clean-up with mild soap and water.

WARRANTY:

1 year manufacturer's warranty against manufacturing defects.