



Terrazzo8™ Installation Instructions

1 INTRODUCTION

- 1.1 Terrazzo8™ Tile is a precast terrazzo tile recommended for indoor use only.
- 1.2 Terrazzo8™ products shall be installed by experienced professional installers with a minimum of 5 years' experience.
- 1.3 Substrate testing and preparation shall follow industry standards (quoted herein in italics) and the following installation guidelines. For situations that are not covered in this document, contact Allstate.
- 1.4 Terrazzo8™ Tile is a natural product and each tile is individually cast, no two tiles are exactly the same. For this reason, it is necessary to dry lay the floor tile in sequenced courses, prior to installation to inspect and ensure that the visual properties will flow smoothly from one tile to the next. The installer shall dry lay the tiles, step back and review the appearance of the installation before proceeding. Tiles should be turned or rotated as necessary in order to achieve a more uniform look. Installation of tile with obvious visual defects or shading is not covered under warranty.
- 1.5 For situations that are not covered in this document, contact Allstate.

2 MATERIAL HANDLING AND STORAGE

- 2.1 Upon receipt, inspect product for damage and mark shipping documents as such before signing for shipment. Contact shipper and/or Allstate. to report damage. If material is distorted or otherwise damaged during storage or transportation, do not install.
- 2.2 Handle Terrazzo8™ Tiles with care. Tiles can be broken if not handled carefully and placed on a smooth, hard and flat substrate.
- 2.3 Protect all materials, including but not limited to, underlayment panels, patching/leveling compounds, floor covering, adhesive, and maintenance products from extremes of temperature during shipping. Some products must not be allowed to freeze. Store all products in areas on the job site where they are to be installed. Areas shall be enclosed and weather tight, at 65°F - 80°F for a minimum of 48 hours prior to starting installation.

allstaterubber.com

Allstate Rubber 1099 Wall Street West | Suite 169
Lyndhurst, New Jersey 07071
P: 718 526 7890



Terrazzo8™ Installation Instructions

2 MATERIAL HANDLING AND STORAGE (Cont.)

- 2.4 Prior to installation, place Terrazzo8™ on a smooth, flat and hard substrate in 3-inch stacks to acclimate to the room temperature for a minimum of 48 hours. The edges of the stacked material must line up, no overhanging of material is allowed. Otherwise cupping may occur. Proper acclimation of Terrazzo8 will reduce the potential of cracking or breakage during routine handling.
- 2.5 Inspection of materials: Great care is taken to properly label and inspect materials for defects at all phases of manufacturing and handling by Allstate. In the rare case where the wrong product or material with visible defects is shipped, these products shall not be installed. Careful inspection of the product before installing is the responsibility of the installer. Installation of the product denotes acceptance of the product. Allstate will not honor any warranty or requests for return authorization for materials installed in the wrong color, with visible defects or other damage

3 SUBSTRATE PREPARATION AND TESTING

- 3.1 All substrates must be sound, clean, permanently dry, smooth, and free of cracks and contaminants including, but not limited to; paint, old adhesive, curing compounds, oil, grease, wax, asphalt, or other contaminants that could affect the adhesive bond. Any and all contaminants must be removed by mechanical means only. Do not use chemical adhesive or contaminant removers.
- 3.2 CONCRETE SUBSTRATES:
 - 3.2.1 Follow guidelines of ASTM F710 Standard Practice for Preparing Concrete Floors to Receive Resilient Flooring*. ASTM F710 includes but is not limited to, requirements for moisture testing, smoothness, flatness, concrete strength, and the presence of a vapor retarder beneath the slab.

Terrazzo8™ Installation Instructions

3 SUBSTRATE PREPARATION AND TESTING (Cont.)

- 3.2.2 The installation of a permanent, effective moisture vapor retarder with a minimum thickness of 0.010 in. and a permeance of 0.1 y, as described in Specification ASTM E 1745 is required under all on- or below-grade concrete floors. The use of such a moisture vapor retarder, provided its integrity has not been compromised, reduces potential severity of water vapor penetration. Every concrete floor slab on- or below-grade to receive resilient flooring shall have a water vapor retarder (often improperly called a vapor barrier) installed directly below the slab.*
- 3.2.3 Joints such as expansion joints, isolation joints, or other moving joints in concrete slabs shall not be filled with patching compound nor covered with resilient flooring*. Do not install Terrazzo8™ over expansion joints or other moving joints. Use an expansion joint cover or expansion joint profile; see section 6.4.1 for more information.
- 3.2.4 The concrete slab shall be tested for moisture, regardless of age or grade level.* The only acceptable test methods are the Calcium Chloride test (ASTM F 1869) and Relative Humidity test (ASTM F 2170). Moisture meters, plastic sheet test or other methods are not acceptable for determining the suitability of concrete slabs to receive resilient floor coverings. It is recommended testing be conducted by a qualified independent testing agency with experience conducting ASTM F 1869 and ASTM F 2170 testing. Test procedures shall be followed exactly in order for test results to be valid. Building shall be at in-service temperature and humidity, concrete shall be properly cleaned, and recommended number of tests shall be conducted. See ASTM standards for details.
- 3.2.5 Test methodology and test results shall be documented and provided to the flooring contractor, general contractor, owner and/or architect.

Terrazzo8™ Installation Instructions

3 SUBSTRATE PREPARATION AND TESTING (Cont.)

3.2.6 If concrete moisture conditions are outside the adhesive manufacturer's limits per section 5, do not commence installation. Allow the concrete to fully dry or apply a 100% solids epoxy Moisture Mitigation System. Although Allstate does not endorse or prefer any manufacturer in particular, we provide the following list of leading Moisture Mitigation System manufacturers for information purposes only.

Ardex: 724.203.5000 (www.ardex.com)

Bostik: 978.777.0100 (www.bostik-us.com)

Koester: 757.425.1206 (www.koesterusa.com)

Mapei: 800.426.2734 (www.mapei.us)

3.3 WOOD SUBSTRATES:

3.3.1 For wood subfloor systems, ensure the subfloor conforms to the guidelines of ASTM F1482, Guide to Wood Underlayment Products Available for Use Under Resilient Flooring. A typical wood subfloor system includes a joist spacing of 16" on center with a double layer subfloor/underlayment system - minimum one inch thickness.

3.3.2 Wood subfloor systems shall be suspended at least 18" above the ground. Crawl spaces shall have adequate cross ventilation and a moisture barrier shall be used on the ground to reduce humidity from ground moisture.

3.3.2 Do not install product over lauan panels, plywood with knots, OSB, hardwood flooring, treated wood (i.e. CCA, fire-rated plywood, or other coated wood), particle board, chipboard, flakeboard, fiber board, Masonite™, pressboard, or other hardboard underlayment, or other uneven or unstable substrates. To cover unsuitable substrates in a wood subfloor system, use underlayment grade plywood (i.e. arctic birch panels or A/C plywood).

3.3.3 Consult ASTM F 1482 or underlayment manufacturer for recommendations regarding plywood thickness, fastener selection and spacing and conditioning of panels.

Terrazzo8™ Installation Instructions

3 SUBSTRATE PREPARATION AND TESTING (Cont.)

3.4 GYPSUM SUBSTRATES

- 3.4.1 Do not install over trowel applied gypsum patching compounds.
- 3.4.2 Do not use poured gypsum underlayment over concrete slabs on or below grade
- 3.4.3 Compressive strength: Gypsum underlayment, for commercial installations, shall provide a minimum of 3000 psi compressive strength after 28 days*. If the finished floor will be in a commercial use, this standard must be followed. Underlayment shall be mixed according to manufacturer's guidelines.
- 3.4.4 Drying Time: Manufacturer's recommended drying time and recommended testing method for dryness shall be followed. Usually a specific moisture meter is recommended by the manufacturer. The calcium chloride test method is not acceptable for testing gypsum underlayment.
- 3.4.5 Sealer/primer: After drying and prior to installing adhered floor coverings, Gypsum underlayment shall be sealed/primed per the underlayment manufacturer's instructions for covering the underlayment with adhered floor coverings. If the underlayment is not sealed, the surface will be overly porous and the floor covering adhesive will not work correctly.
- 3.4.6 Patching or "skim coating" over gypsum substrates: There are a number of patching compounds that can be used over gypsum underlayment. Follow compound manufacturer's instructions for doing so. It may be necessary to prime the gypsum substrate prior to patching.

3.5 DO NOT INSTALL OVER EXISTING RESILIENT FLOOR COVERINGS.

- 3.5.1 Concrete Subfloors: Existing resilient floor coverings and adhesives over concrete shall be removed and the concrete shall be repaired using a cement based patching or leveling compound per manufacturer's guidelines. All adhesive residue must be removed prior to installing. Also remove any floor patch below the adhesive layer. Do not use chemical adhesive removers. Black asphaltic adhesive can be scraped to

Terrazzo8™ Installation Instructions

3 SUBSTRATE PREPARATION AND TESTING (Cont.)

3.5 DO NOT INSTALL OVER EXISTING RESILIENT FLOOR COVERINGS. (CONT.)

3.5.1 a thin, well-bonded residue and encapsulated with an approved patching or leveling compound per manufacturer's instructions. All other adhesive (carpet adhesive, VCT adhesive, epoxy, etc) shall be completely removed from concrete substrates.

3.5.2 Wood Subfloors: Existing resilient floor coverings and/or adhesive residue over a wood subfloor system shall be covered with a plywood underlayment per section 3.3.

3.5.3 NOTE: If removal of existing resilient flooring or adhesive is required, follow "Recommended Work Practices for Removal of Resilient Floor Coverings" available from the Resilient Floor Covering Institute at 706-882-3833 or www.rfci.com. Also, be aware that existing floors and/or adhesives may contain asbestos or lead. Various federal, state, and local government agencies regulate the removal of lead or asbestos containing material. Review and comply with all applicable regulations.

3.6 Poured Floors (Epoxy, Polymeric, seamless): Terrazzo8™ Tile may be installed over most poured floors provided that the concrete substrate beneath the poured floor has been tested for moisture and meets the limits per section 3.2. Poured floors must also meet the following guidelines:

3.7 Poured floor shall be totally cured and well bonded to the concrete and free of any residual solvents and petroleum derivatives. Loose or damaged areas and irregularities must be repaired with cement based patching compound.

3.7.1 The texture must be smooth. Mechanically prepare the surface to remove any grit and texture.

3.7.2 All waxes and finishes must be removed and rinsed with clean water and a pH test should be conducted to assure stripper residues have been removed.

3.7.3 After area has been properly prepared, adhesive bond tests must be conducted (and passed) with the flooring and adhesive that will be used on the job.

Terrazzo8™ Installation Instructions

3 SUBSTRATE PREPARATION AND TESTING (Cont.)

- 3.8 Other substrates such as terrazzo, stone, ceramic tile, metal: Cover with cement based underlayment compound per the manufacturer's instructions and ensure compliance with ASTM F 710 for use of these compounds.
- 3.9 Do not install over non-compatible substrates such as asphalt, bituminous or asphalt-saturated material.
- 3.10 Terrazzo8™ is a flexible product that conforms to the substrate beneath it, and it requires special attention to substrate preparation. Any irregularities in the substrate or improper substrate leveling and/or preparation may cause tiles to appear to be out of square or have unacceptable lippage (differences in elevation between adjacent tile edges). In addition to the general requirements stated in the following subsections regarding substrate preparation, successful installation of Terrazzo8™ requires a specific flatness tolerance of no greater than 1/8" in 10'.
- 3.11 Radiant Heat: Terrazzo8™ can be installed on radiant heated slabs providing the maximum temperature of the surface of the slab does not exceed 85°F (29°C) under any condition of use. * To allow proper adhesion of the adhesive to the subfloor, the radiant heating system should be lowered, or turned off for at least 48 hours prior to installation of the flooring material. The room temperature must be maintained at a minimum of 65°F prior to, during and after installation for 72 hours after which the temperature of the radiant heating system can be increased. When raising the floor temperature, do so gradually so that the substrate and the flooring material can adapt to the temperature change together. A rapid change could result in bonding problems.

4 SITE CONDITIONS

- 4.1 Install new floor coverings after all other trades have completed their work.
- 4.2 Protect areas where floor covering shall be installed from all traffic before, during and after installation.
- Extremes of temperature and humidity can affect floor covering products and can alter the proper cure of patching compounds and adhesives. Building shall be between 65°F and 80°F for 48 hours before installation, during installation and for 48 hours after installation. Thereafter, maintain a minimum temperature of 55°F and relative humidity of 35% - 65%.

Terrazzo8™ Installation Instructions

4 SITE CONDITIONS (Cont.)

- 4.3 NOTE: If a system other than a permanent HVAC system is utilized, it must provide constant temperature and humidity control at specified levels for the specified time frame.
- 4.4 Maximize fresh air ventilation by using exhaust fans at point of use. Face fans out of the area where flooring is being installed, not into the area. Never force dry adhesives or patching compounds by using fans.

5 ADHESIVE AND ACCESSORIES

- 5.1 Mapei Eco 373 is the approved adhesive for installing Terrazzo8™
- 5.2 100-pound, 3 part roller

6 INSTALLATION

- 6.1 See section 10 for Installation Tools Checklist.
- 6.2 Thoroughly vacuum the substrate to remove all dirt and debris.
- 6.3 LAYOUT
 - Follow the layout specified by the end user, architect, or designer. Terrazzo8™ can be laid out to run either parallel or diagonal to the room or primary wall.
 - 6.3.1 If any of the following elements are specified or included as part of the design, please contact Allstate directly before proceeding with installation.
 - 6.3.1.1 Metal strips or metal expansion joint profiles - often used as an alternative to cover expansion joints or other moving joints in a concrete slab.
 - 6.3.1.2 "Snap down" or "T" moldings - often used to transition between floor coverings.
 - 6.3.2 Prior to laying out the material, measure and mark control lines on the floor in pencil. Terrazzo8™ tile is installed using standard tile installation techniques. It is customary to start from the center of the room. In corridors and small spaces, it may be simpler to work lengthwise from one end, using the center line as a guide.
 - 6.3.3 Installation Method: Terrazzo8™ is installed using "Butt Joint" method. For "Butt Joint" method, install the tiles snugly against adjacent tiles. There should be no gaps between tiles.

Terrazzo8™ Installation Instructions

6 INSTALLATION (Cont.)

- 6.3.4 Tile must be rolled to make sure that the tile is firmly set into the adhesive and to avoid any lippage.
- 6.3.5 Extremes of temperature and humidity can affect floor covering products and can alter the proper cure of patching compounds and adhesives. Building shall be between 65°F and 80°F for 48 hours before installation, during installation and for 48 hours after installation. Thereafter, maintain a minimum temperature of 55°F and relative humidity of 35% - 65%.

NOTE: If a system other than a permanent HVAC system is utilized, it must provide constant temperature and humidity control at specified levels for the specified time frame.

- 6.4 Maximize fresh air ventilation by using exhaust fans at point of use. Face fans out of the area where flooring is being installed, not into the area. Never force dry adhesives or patching compounds by using fans.

7 ADHESIVE AND ACCESSORIES

- 7.1 Terrazzo8™ is installed using ECO 373. This is the only approved adhesive.
- 7.2 Use 100 pound, 3 part roller, and hand roller where the large roller can't reach

8 CLEAN UP AND FINAL FINISH

8.1 SEALING

Do not leave the floor unprotected without applying sealer. A penetrating sealer protects the floor and provides a base coat for the application of floor finish.

- 8.1.1 Remove all soil, debris, sand and grit by sweeping, dust mopping or vacuuming.
- 8.1.2 Scrub floor with a neutral pH (7-8.5) detergent, such as Diversey Stride, Hillyard Super Shine All, or equivalent.
- 8.1.3 Apply cleaning solution with a mop and bucket using as little water as possible. Do not flood the floor.
- 8.1.4 Scrub with a rotary scrubber or automatic scrubber with scrubbing pad.
- 8.1.5 If necessary, remove cleaning solution with a wet-vac.

Terrazzo8™ Installation Instructions

8 CLEAN UP AND FINAL FINISH (Cont.)

- 8.1.6 Rinse with clean water and allow floor to dry thoroughly. Surface must be completely dry before applying sealer.
- 8.1.7 Apply penetrating sealer, such as Hillyard Terrazine, with a clean finish mop or finish applicator. NOTE: Only thin coats are required (less is more). Ensure the sealer gets into the tile joints.
- 8.1.8 Allow first coat to dry thoroughly (at least 30 minutes) before applying second coat.
- 8.1.9 Apply second coat of sealer in opposite direction of first coat.
- 8.1.10 Apply Floor Finish after second coat of sealer is completely dry, see section 8.

9 INITIAL MAINTENANCE

- 9.1 Floor finish such as Hillyard North Star can be applied immediately after the sealer is dry. If the floor finish is not applied directly following the application, thoroughly clean and rinse the floor before applying floor finish. Follow Terrazzo8™ maintenance instructions.
- 9.2 If construction is to continue after the floor is installed, the floor must be protected from damage. After the floor is installed, polished and the final coat of sealer has completely dried, sweep or vacuum the floor and then cover with brown Kraft paper to protect. If floor will be exposed to rolling traffic, you must cover the Kraft paper with plywood or hardboard panels.
- 9.3 Entrance matting: Because 90% of all dirt in a building comes in on footwear, Allstate recommends installing and maintaining entrance matting (preferably permanently installed) at all outdoor entrances (20-30 linear feet for major entrances; less for infrequently used entrances). Doing this will improve, reduce flooring maintenance costs, and lengthen the life of your floors.
- 9.4 Furniture: To minimize the chance of damage, proper glides must be used on chairs and other furniture that slide directly across the floor. Chairs must have glides that are a minimum of 1 inch in diameter. Heavy items (such as equipment, appliances, fixtures, heavy furniture) shall not be moved directly across the floor. Using protective boards will reduce the chance of damage in these cases.



Terrazzo8™ Installation Instructions

9 INITIAL MAINTENANCE (Cont.)

- 9.5 Sunlight: Direct sunlight can damage most interior finishes so proper protection in the form of window coverings is recommended.
- 9.6 On-going Maintenance: download Terrazzo8™ instructions via WWW.ALLSTATERUBBER.COM

All terms & procedures are subject to change without notice.

allstaterubber.com

Allstate Rubber 1099 Wall Street West | Suite 169
Lyndhurst, New Jersey 07071
P: 718 526 7890

Terrazzo8™ Installation Instructions

10 INSTALLATION TOOLS CHECKLIST

- ___ 1/16" Square notch adhesive trowels
- ___ 10' and 8' straight edges
- ___ 17" Flexible Velcro Drive Head
- ___ 17" Mastercraft, Quarry Master Buffer w/ Water Tank / 40 – 50 lb. Weights
- ___ 2" Putty knife
- ___ 2" Wall Grout Float***
- ___ 3 Large Trash Bags
- ___ 3 Looped End, Cotton/Rayon Finish Mops
- ___ 3" Diamond Lippage Plates (70 / 120 Grit)
- ___ 3" Diamond Polishing Pads (70 / 120, 220, 400 grit)
- ___ Angle Grinder (for dry cutting)
- ___ Blue Painters Tape
- ___ Cap snips
- ___ Cleaning: Mop, bucket w/ wringer
- ___ Color Coordinated Silicone Caulk
- ___ Continuous rim diamond blade (for dry cutting)
- ___ Extension cords
- ___ Fox Tail / Rat Tail Brush
- ___ Hammer
- ___ Hand Roller
- ___ Heat Gun
- ___ Personal Protection: Gloves, safety glasses, booties, suit, etc.
- ___ Polyethylene Sheets or Roll Goods
- ___ Razor Scraper & Blades
- ___ Saw Horses and plywood for cutting surface
- ___ Suction Cups to lift tile
- ___ Wet Saw
- ___ Wet/Dry Vacuum
- ___ White Cotton Rags
- ___ 100-pound, 3-part roller

****Sanitary Cove Base projects

* ASTM Standard F 710 Standard Practice for Preparing Concrete Floors to Receive Resilient Flooring, ASTM International, West Conshohocken, PA, 2003, www.astm.org.

** ANSI (American National Standards Institute) standard A108.02.

allstaterubber.com

Allstate Rubber 1099 Wall Street West | Suite 169
Lyndhurst, New Jersey 07071
P: 718 526 7890

All specifications & instructions are subject to change without notice.